



## PREFORMED SHAPE INSTALLATION: OUTSIDE CORNER

**1. Install Hyload Flashing** membrane into block back-up wall per plans and specifications. Install membrane to the corner of back-up wall.

**2. Cloaks** are installed when the bricks are laid. Adhere membrane to cloak using Hyload Flashing Membrane Adhesive.

